

# SEMI AUTOMATIC STRIKER FIRED PISTOL MAINTENANCE

## PARTS:


- Frame
- Slide
- Barrel
- Recoil Spring Assembly

## CLEANING

- Toothbrush:** scrub the frame, slide, & feed ramp
- Micro Fiber Cloth:** wipe away all residue
- Barrel Brush:** add oil or barrel cleaner and push through the barrel
- Lubricate:** small drops spread with the fingertip

## LUBRICATION

- Rails and rail guides
- Connector
- Trigger Bar (2 points)
- Safety Plunger
- Top & bottom of barrel, inside top of slide



[www.okctactical.com](http://www.okctactical.com)  
405-888-9254

**Frame** **Barrel** **Slide**



**Safety Plunger** **Recoil Spring Assembly** **Slide Rails**  
**Striker**



**Ejector** **Slide Stop** **Slide Guides**



**Connector** **Trigger Bar** **Feed Ramp**

**Lubricate:**  
**Metal on metal contact points**



**We recommend a light oil that will not suspend particulates.**